


Wheels motor

Motor: 220 rpm

Stroke: unlimited forward and backward

Zero position sensor: none, robot uses [magnetic marker sensor](#) to zero position errors in the robot's direction

The wheels motor is used to take new positions in the robot's direction in order to continue to wash predominantly with [tower](#), [arm](#) and [nozzle](#).



[See the exploded view of the wheels motor and gearbox here](#)

From:
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:wheels_motor?rev=1601198996

Last update: **2020/09/27 02:29**

