

# SMS

On the Internet screen, a mobile phone number can be entered in order to receive SMS messages from the robot. There are mainly 2 types of SMS messages that are sent from the robot: alarms and finished.

## Alarm SMS

*Alarm!*

*The arm got stuck when it tried to move out.*

*ID: Stuck 9*

*For more info visit:*

<https://wiki.envirologic.se/doku.php/sms/> *The information given in an alarm SMS is the following: \* Alarm type, can be any of the following: \* First marker not found \* Robot stuck, the code shows motor and direction: \* 0 = any \* 1 = boom up \* 2 = boom down \* 3 = tower right \* 4 = tower left \* 5 = robot backward \* 6 = robot forward \* 7 = telescope out \* 8 = telescope in \* 9 = arm out \* 10 = arm in \* 11 = nozzle clockwise \* 12 = nozzle counter-clockwise \* Control system error \* Hose stuck \* Pressure fault, the code shows how: \* 1 = too high \* 2 = too low \* Ongoing run aborted \* Battery low, the code shows when: \* 1 = active \* 2 = idle ===== Finished SMS ===== +46712345678 HOUSE\_3 finished*

*IMSI: 234567890123456 The information given in a finished SMS is the following: \* Recipient phone number (used by a server to determine where to send the message from the robot) \* Finished location \* SIM card identification number ===== Test SMS ===== A test SMS triggered from the Internet screen looks like this: +46712345678*

*Modem Test OK*

*IMSI: 234567890123456*

From:

<https://wiki.envirologic.se/> - Envirologic Support Wiki



Permanent link:

<https://wiki.envirologic.se/doku.php/sms?rev=1645002582>

Last update: **2022/02/16 01:09**