

# Problem with motor

## Description

Motor issues can arise from a number of reasons:

- Damaged cables leading to circuit breaks or short circuits
- Damaged connectors or water ingress in connectors
- Bad connection in connectors
- Damaged gears
- Overheated motor

## Troubleshooting

Always troubleshoot the motor from the [Manual screen](#). Run it at least 5 seconds in each direction. Press the “i” button for a detailed view. If the robot gives an alarm, check the [troubleshooting guide](#) for that specific alarm.

- Does the position counter change? If not, check the pulse signal and power cables.
- Does the function move physically? If not:
  - Does any sound come from the motor? If it does, the function could be physically stuck or the gear can be damaged. No sound? Check cables
  - Does the motor draw any current? If not, check the cables.
- Check that the emergency stop button is not pressed down
- Spray connectors with 5-56 or WD-40
- If you have access to a spare motor you can connect it temporarily to the connector in order to troubleshoot the function. Remember to ground it properly, e.g. by holding a motor metal part against robot chassie

From:

<https://13.53.123.107/> - **Envirologic Support Wiki**

Permanent link:

[https://13.53.123.107/doku.php/troubleshooting:no\\_alarm:motor\\_problem](https://13.53.123.107/doku.php/troubleshooting:no_alarm:motor_problem)

Last update: **2023/09/14 22:48**

