# Robot components

To read more about some of the most important components, click the corresponding link below.

---

## A

Accessories

Antenna

Arm

## B

Batteries

Boom

## C

Center wheel

Charger

Charging

Circuit board

Clutch handle

Connectors

Computer

## D

Display

Double nozzle / Shift head valve

# E

Emergency stop

# F

Friction clutch

Fuses

# G

Guidance wheels

# H

Högtryckstvätt

Hose

Slangvinda och huvudslang

Hose spreader

# I

# J

Joystick

Junction box

# K

# L

# M

Magnetic markers - Types

Magnetic markers - Explained

Magnetic switch

Motors

# N

Nozzle motor

Nozzle types

# O

Operators panel/display

# P

Panel

Parking positions

PCB

Pressure sensor

Print board

PLC

Pulse sensors

# Q

# R

Router

# S

Screens

Shift head valve

Side wheels

SMS

Support wheels

# T

Telescope

Tower

Transport wheel

# U

# V

Virtual markers

# W

Water filter

Water strainer/filter

Water valve

Wheels motor

Wheel types

Wi-Fi

# X

# Y

# Z

Zero position sensors

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
**https://wiki.envirologic.se/doku.php/parts:components?rev=1604666979**

Last update: **2020/11/06 04:49**