Junction box

The junction box is found under the hood. It contains the control system electronics and system fuses.

Link: **Exploded view of the junction box assembly.**

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:junction_box?rev=1601292855

Last update: **2020/09/28 04:34**