Telescope brake

The telescope brake offloads the motor when the motor is not moving. This means that the telescope only can move when driven by the motor.

See drive unit assembly

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:telescope_brake

Last update: **2021/07/19 13:10**