Telescope brake

The telescope brake offloads the motor when the motor is not moving. This means that the telescope only can move when driven by the motor.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:telescope_brake?rev=1626725243

Last update: **2021/07/19 13:07**