Washing aborted unexpectedly

Description

The Start screen is showing but the washing has not finished and the robot has not returned to the first marker.

Troubleshooting

- Check that the robot has not restarted during washing. It should raise an alarm if it has.
- Check for dirt under the panel lid, possibly pressing on the screen

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:washing_aborted

Last update: **2020/09/14 02:35**