

**Alarm Code:**

19. Boom not parked

**Context where the error occurs:**

The boom has not reached the parking position when completing the teaching process or after a manual run.

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/cc:alarm\\_19](https://wiki.envirologic.se/doku.php/cc:alarm_19)

Last update: **2021/04/16 03:09**

