Alarm Code:

19. Boom not parked

Context where the error occurs:

The boom has not reached the parking position when completing the teaching process or after a manual run.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/cc:alarm_19

Last update: **2021/04/16 03:09**