Alarm Code:

20. Tower not parked

Context where the error occurs:

The tower has not reached the parking position when completing the teaching process or after a manual run.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/cc:alarm_20

Last update: **2021/04/16 03:10**