Alarm Code:

22. Arm not parked

Context where the error occurs:

The arm has not reached its parking position when completing the teaching process or when starting after a manual run.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/cc:alarm_22

Last update: **2021/04/16 03:12**