

Alarm Code:

7. Max distances stored

Context where the error occurs:

This type of alarm is the second step in the alarm connected to the teaching memory. The first step is reached 50 distances before (see alarm 17). After acknowledging this alarm, the operator can complete the teaching process using the last 50 distances. If not, this second step alarm appears when the memory capacity of 1020 distances has been used for this particular pen type.

Note: The only way to escape from this situation is to reboot the system using the main switch, and the pen type will then NOT be stored

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/cc:alarm_7

Last update: **2021/04/16 02:50**

