



Items Number	Parts Number	Description	Quantity
1	1109201-6		1
2	1109202-1		1
3	409216-1-0a4	Arm	1
4	1101030-1		2
5	ISO 7089 - 6	Washer M6	1
6	ISO 4032	Nut M6	1
7	409212-1-0a1	Arm	1
8	93187252-M-0a33	Rear Wheel Driving Assembly	1
9	409211-2-0a0	Arm	1
10	1107030-3	Welded Assembly	1
11	1109205-1	Arm	1
12	409215-1-0a3	Arm	1
13	1107041-1-0a16	Front Wheel Assembly	1
14	ISO 4032	Nut M10	10
15	409213-1-0a2	Arm	1
16	941021-1-0a25	Screw M8 x 30	2
17	941020-1-0a18	Nut M8	2

Items Number	Parts Number	Description	Quantity
18	941016-1-0a37	Washer M8	4
19	901036-1-0a28	Wall Mounted Bearing	1
20	401059-2-0a19	Plate	1

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/chassi\\_below?rev=1572884379](https://wiki.envirologic.se/doku.php/chassi_below?rev=1572884379)

Last update: **2019/11/04 08:19**

