


Boom

Motor: special actuator

Stroke: bottom position 0 to top position 1250, about 100°

Parking: about 710, horisontal

The boom is used to take new elevations in order to continue to wash predominantly with tower, arm and nozzle.



[See the exploded view of the boom here](#)

From:
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:
<https://wiki.envirologic.se/doku.php/parts:boom?rev=1600848211>

Last update: **2020/09/23 01:03**

