

# Robot components

To read more about some of the most important components, click the corresponding link below.

---

## A

[Accessories](#)

[Antenna](#)

[Arm](#)

## B

[Batteries](#)

[Boom](#)

## C

[Center wheel](#)

[Charger](#)

[Charging](#)

[Circuit board](#)

[Clutch handle](#)

[Connectors](#)

[Computer](#)

[Corner wheels](#)

## D

[Display](#)

[Double nozzle / Shift head valve](#)

## **E**

[Emergency stop](#)

## **F**

[Friction clutch](#)

[Fuses](#)

## **G**

[Guidance wheels](#)

## **H**

[High-pressure washer](#)

[Hose](#)

[Hose reel](#)

[Hose spreader](#)

## **I**

## **J**

[Joystick](#)

[Junction box](#)

## **K**

## **L**

## M

[Magnetic markers - Types](#)

[Magnetic markers - Explained](#)

[Magnetic switch](#)

[Motors](#)

## N

[Nozzle motor](#)

[Nozzle types](#)

## O

[Operators panel/display](#)

## P

[Panel](#)

[Parking positions](#)

[PCB](#)

[Pressure sensor](#)

[Print board](#)

[PLC](#)

[Pulse sensors](#)

## Q

## R

[Router](#)

## S

[Screens](#)

[Shift head valve](#)

[Side wheels](#)

[SMS](#)

[Support wheels](#)

## T

[Telescope](#)

[Telescope brake](#)

[Tower](#)

[Transport wheel](#)

## U

## V

[Virtual markers](#)

## W

[Water filter](#)

[Water strainer/filter](#)

[Water valve](#)

[Wheels motor](#)

[Wheel types](#)

[Wi-Fi](#)

**X****Y****Z**[Zero position sensors](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

<https://wiki.envirologic.se/doku.php/parts:components?rev=1626725057>Last update: **2021/07/19 13:04**