Robot components

To read more about some of the most important components, click the corresponding link below.

A

Accessories

AGM battery

Aisle and robot measurements

Antenna

Arm

B

Batteries

Boom

C

Center wheel

Charger

Charging

Circuit board

Clutch handle

Connectors

Computer

Corner wheels

D

Display

Double nozzle / Shift head valve

E

Emergency stop

F

Friction clutch

Fuses

G

Guidance wheels

H

Högtryckstvätt

Hose

Slangvinda och huvudslang

Hose spreader

I

J

Joystick

Junction box

K

L

M

Magnetic markers - Types

Magnetic markers - Explained

Magnetic switch

Measurements

Motors

N

Nozzle motor

Nozzle types

O

Operators panel/display

P

Panel

Parking positions

PCB

Pressure sensor

Print board

PLC

Pulse sensors

Q

R

Router

S

Screens

Shift head valve

Side wheels

SMS

Support wheels

T

Telescope

Telescope brake

Temperature

Tower

Transport wheel

U

V

Virtual markers

W

Water filter

Water strainer/filter

Water valve

Wheels motor

Wheel types

Wi-Fi

X

Y

Z

Zero position sensors

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:components?rev=1645989113

Last update: **2022/02/27 11:11**