Connectors

Batteries

The batteries are connected with quick release type connectors. To avid short circuits when replacing the batteries, always first remove the connector from the minus pole of the battery connected to the robot. Consequently, always reconnect this pole last.

Motors

The motors are connected with sealed connectors. The most exposed ones (arm and nozzle) are striped with cable ties for extra water protection.

Joystick

The joystick connector is located under the hood on the right side of the robot.

Charger

The charging connector is located on the back side of the robot below the panel.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:connectors?rev=1600669845

Last update: **2020/09/20 23:30**