

# Emergency stop

The emergency stop button immediately cease all movements when pushed. This means all motors and actuators will stop and the water valve will close.

The button is located just below the operators panel.

---

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/parts:emergency\\_stop?rev=1593766429](https://wiki.envirologic.se/doku.php/parts:emergency_stop?rev=1593766429)

Last update: **2020/07/03 01:53**

