

Hose reel

The hose reel holds the robot's high pressure water hose. A 50 m hose is standard on the robot but it can be fitted with either 60 m or 70 m hose too.

The hose reel is powered by a dedicated motor (220 rpm), located under the hood on the left side of the reel. It is activated when the robot moves backwards or when manually activated on the Manual screen.

A [hose spreader](#) arm distributest the hose evenly on the reel.

Take care to protect the hose from unnecessary [wear](#).

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/parts:hose_reel?rev=1601199361

Last update: **2020/09/27 02:36**

