

Nozzle motor


Motor: 70 rpm with D-profile

Stroke: unlimited 360° in both directions

Parking: about 0, pointing down when arm is parked (however dependent on the angle the nozzle has been fastened with at the end of the arm)

Zero position sensor: internal

The nozzle is one of the circular movements of the robot and should be used predominantly together with the tower and the arm during washing.



[See the exploded view of the arm here](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/parts:nozzle_motor?rev=1600921840

Last update: **2020/09/23 21:30**

