
Telescope

Motor: 70 rpm

Stroke: retracted position 0 to extended position 425, about 160 cm

Parking: fully retracted at 0

The telescope is used to increase the washing distance from the robot in order to continue to wash predominantly with tower, arm and nozzle.



See the exploded view of the telescope here

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:telescope

Last update: **2020/09/24 07:21**