# Tower


Motor: 70 rpm

Stroke: 1000 in both directions from parking position, about ±200°

Parking: about 0, straight forward (read more here)

Zero position sensor: about 0

The tower is one of the circular movements of the robot and should be used predominantly together with the arm and the nozzle during washing.



See the exploded view of the tower and gearbox here

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
**https://wiki.envirologic.se/doku.php/parts:tower_motor?rev=1600927094**

Last update: **2020/09/23 22:58**