Transport wheel

The transport wheel (center wheel) is used to make it easier to turn (pivot) the robot or to climb level differences and thresholds. It is operated from the Manual screen where it can be lowered or raised.

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/parts:transport_wheel

Last update: **2020/09/21 00:00**