

Water filter

We recommend to use a water filter with the incoming water to the [high-pressure washer](#) (filter placed before the high-pressure washer). Water isn't always clean and the particles can make wear and tear on the high-pressure washer and the nozzle. Dirty water can also clog the water valve, which leads to ["Water pressure too high"-alarm](#).

The filter is simple to remove and clean when the filter is full of dirt.



A water filter

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/parts:water_filter?rev=1601008944

Last update: **2020/09/24 21:42**

