

Wi-Fi

All EVO Cleaners from year 2020 have Wi-Fi settings. The Wi-Fi connection makes it possible for the robot to communicate even though its mobile signal is non-existent. The Wi-Fi feature requires an installed Wi-Fi at the farm. If the Wi-Fi at the farm is weak at certain areas and the robot lose the Wi-Fi connection, it will automatically go over to mobile signal until it has Wi-Fi connection again.

Once the robot is connected to a Wi-Fi and the feature is enabled, the robot will automatically connect to this Wi-Fi at each start-up (it can take up to two minutes when starting the robot to retrieve the Wi-Fi signal).




The robot do not support Wi-Fi names (SSID) with special letters like Å, Ä, Ö, Æ, Ø




How to connect to Wi-Fi

Step 1. From start screen, go to settings.

Step 2. From settings, go to internet screen ( in the top left corner).


Step 3. Press the Wi-Fi settings button.



Step 4. Press the “Wi-Fi disabled” -button to enable Wi-Fi.




Step 5. When the button change color to green and says “Wi-Fi enabled” the robot will search for nearby Wi-Fi's. The robot will list the three strongest signals.
i. It can take up to 2 minutes to list the Wi-Fi's.



Step 6. Once the Wi-Fi's are listed, press the Wi-Fi you want to connect to.


! The robot do not support Wi-Fi names (SSID) with special letters like Å, Ä, Ö, Æ, Ø **!**
i. Is your Wi-Fi not listed? You can tap the large button at the top of the screen and enter the correct name (SSID) for the Wi-Fi you wish to connect to. Notice that you must spell the name/SSID of the Wi-Fi correctly.



Step 7. Once you have selected/entered your Wi-Fi you will see a “Enter Wi-Fi password” -button at the bottom of the screen.

Step 8. Press the “Enter Wi-Fi password” -button and type the Wi-Fi password.

Step 9. The robot connects to the Wi-Fi. Wait until you can see a signal in the Wi-Fi bar at the top of



the screen.

You are now connected to the Wi-Fi.

From: <https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link: <https://wiki.envirologic.se/doku.php/parts:wifi?rev=1601013562>

Last update: **2020/09/24 22:59**

