

Service instructions


Here you can find various types of instructions that will help you with different kind of tasks.
More to come...

If the robot has lost its home sensors (zero positions).

- [Homing](#)
-

If the water valve is plugged with dirt (for example due to dirty water) the water can't turn off as normal.

- [Water valve cleaning](#)
-

When you see this symbol  (CD-disc on top of a box) on the start screen, it means that you have an update to install. Please install the update the soonest for best performance. Read [Software revisions](#) to see what the latest changes are.

- [Install an update](#)
-

[Sliding plates replacement](#)

- [High friction in the telescope - troubleshooting](#)

[Hose grows on reel / Loose hose](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/service:service_instructions?rev=1593769158

Last update: **2020/07/03 02:39**

