

# Service instructions

Here you can find various types of instructions that will help you with different kind of tasks.

*More to come...*

---

## Homing

If the robot has lost its home sensors (zero positions).


- [Homing](#)
- 

## Water valve cleaning

If the water valve is plugged with dirt (for example due to dirty water) the water can't turn off as normal.

- [Water valve cleaning](#)
- 

## Install an update

When you see this symbol  (CD-disc on top of a box) on the start screen, it means that you have an update to install. Please install the update the soonest for best performance. Read [Software revisions](#) to see what the latest changes are.

- [Install an update](#)
- 

## Sliding plates

If we sent sliding plates for you to replace.

- [Sliding plates replacement](#)

How to find out if your EVO Cleaner needs a maintenance.

- [High friction in the telescope - troubleshooting](#)
-

## Hose grows on reel / Loose hose

Read this document if your hose frequently are loose on the reel.

- [Hose grows on reel / Loose hose](#)
- 

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/service:service\\_instructions?rev=1593770080](https://wiki.envirologic.se/doku.php/service:service_instructions?rev=1593770080)

Last update: **2020/07/03 02:54**

