
Water valve

The water valve can get blocked/cloged with particles if the incoming water is dirty. Always use a water filter on the incoming water by the high-pressure washer.

Link: How to clean the water valve.



ITEM	DESCRIPTION	PART NUMBER	QTY
1	Magnetic valve	1101100	1
2	Plunge	969202	1
3	Spring	969203	1
4	Plug	969204	1

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/service:spl:1101100-m?rev=1601008816

Last update: **2020/09/24 21:40**