



| Item Number | Parts number | Description | Quantity |
|-------------|--------------|------------------------------------|----------|
| 1 | | Cleaner | |
| 2 | 1409221 | Plate | |
| 3 | 909209 | Gas damper | 1 |
| 4 | | Pin | |
| 5 | 901094 | Sealing tower | |
| 6 | 401060 | Stop washer | |
| 7 | 1109525 | Sensor | |
| 8 | 409230 | Segment | |
| 9 | 409230 | Plate | |
| 10 | | Hose reel complete | |
| 11 | 409220 | Front plate | |
| 12 | 409231 | Plate | |
| 13 | 941062 | Screw M5 x 25 | |
| 14 | 941032 | Nut M5 | |
| 15 | 941087 | Washer M5 | |
| 16 | 1101222 | Electricity box | |
| 17 | | Chassi | |

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/spare_parts_list?rev=1573477757

Last update: **2019/11/11 05:09**

