

# Troubleshoot/repair hose spreader

## Description

The hose spreader spreads the hose so its evenly distributed on the hose reel. For various reasons, it happens that it stops. Here we go through different errors and the solutions to these problems.

1. Start the robot. Lower the det transport wheel so the robot stands with the rear wheels in the air.
  1. Double click on the rear wheel of the robot, this will make the rear wheels lock the drive backwards, the hose reel will try to roll up the hose and the hose spreader will start to swing in its motion.
2. If the hose spreader doesn't move, wait for at least 2 minutes, the hose spreader can stand still and wait at its turning point before turning. If it does not start, then the troubleshooting begins in the hose spreader box.
3. The lid of the box is mounted with 4 screws, one is very narrow but can be removed with a small chisel. Remove the side of the robot to make more space while you work.
4. Due to vibrations in the robot, the connectors may jump of its place. To fix this we put a small amount of MS Polymer on the connector to hold it in place.

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/troubleshoot\\_repair\\_hose\\_spreader?rev=1601557154](https://wiki.envirologic.se/doku.php/troubleshoot_repair_hose_spreader?rev=1601557154)

Last update: **2020/10/01 05:59**

