## **Homing needed**

This is a hard alarm.

## **Description**

Homing has not been performed or the homing positions have been lost and need to be reinitialized. Automatic washing cannot be started before homing is done.

## **Troubleshooting**

Go to the Homing instruction for further guidance.

From:

https://wiki.envirologic.se/ - Envirologic Support Wiki

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:homing\_needed

Last update: 2020/07/15 02:50

