Marker missed

This is a soft alarm.

Description

A marker has not been detected within an expected area during automatic cleaning.

Troubleshooting

- Check alarm screen for the number of the last missed marker
- Check that the marker is correctly mounted
- Check that the magnetic switch arm is correctly adjusted
- Check the distance between marker and magnetic switch
- Check that the magnetic switch is working

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:alarm:marker_missed

Last update: **2020/07/03 02:05**