

# Marker missed

This is a [soft](#) alarm.

## Description

A marker has not been detected within an expected area during automatic cleaning.

## Troubleshooting

- Check alarm screen for the number of the last missed marker
- Check that the marker is correctly mounted
- Check that the magnetic switch arm is correctly adjusted
- Check the distance between marker and magnetic switch
- Check that the magnetic switch is working

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/troubleshooting:alarm:marker\\_missed](https://wiki.envirologic.se/doku.php/troubleshooting:alarm:marker_missed)

Last update: **2020/07/03 02:05**

