

# Troubleshooting - alarms

Which alarm is shown on the screen? If you have already left the alarm screen you can go to Settings>Alarm list>Alarm history.

## General alarms

- [Battery idle voltage low](#)
- [Battery voltage low](#)
- [Ongoing wash aborted unexpectedly](#)
- [Over current detected](#)
- [Water pressure too low](#)
- [Water pressure too high](#)
- [Water turned off due to stuck motors](#)

## Motor alarms

- [Hose reel stuck](#)
- [Motor missing pulses in given direction](#)
- [Motor stuck in given direction](#)
- [No motor current detected](#)
- [Reel missing pulses](#)
- [Robot stuck too many times](#)
- [Telescope stuck](#)
- [Unexpected large position change detected](#)

## Sensor alarms

- [First marker not found within 500 pulses](#)
- [Homing needed](#)
- [Marker magnetic switch failure](#)
- [Marker missed](#)
- [Missing zero position sensor](#)

## System alarms

- [Backup to secondary storage failed](#)
- [File operation failed during recipe edit](#)
- [File operation failed during teach](#)
- [PCB communication failure](#)
- [PCB communication watchdog triggered](#)
- [Remote backup communication error](#)
- [Remote backup preparation failed](#)

- [SELF\\_TEST\\_FAILED](#)
- [Unexpected PCB reset](#)

From:  
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:  
[https://wiki.envirologic.se/doku.php/troubleshooting:alarm:ts\\_alarm?rev=1599817366](https://wiki.envirologic.se/doku.php/troubleshooting:alarm:ts_alarm?rev=1599817366)

Last update: **2020/09/11 02:42**

