

Battery idle voltage low

This is a [soft](#) alarm. However, washing cannot be started.

Description

The battery voltage has gone below 23.5 V during a period where the robot has been idle for more than 10 minutes. Washing cannot be started before the batteries have been charged fully.

Troubleshooting

Charge the [Batteries](#) to more than 25 V.

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tba_battery_idle_voltage_low

Last update: **2020/07/14 13:42**

