

Motor missing pulses in a given direction

This is a [soft](#) alarm.

Description

No movement detected was detected at all when a motor was commanded to move. The alarm indicates both which motor that has failed and in which direction.

Troubleshooting

- Check that pulses are received from given motor
- Check that motor is turning

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tss_missing_pulses?rev=1594729485

Last update: **2020/07/14 05:24**

