

Motor missing pulses in a given direction

This is a [soft](#) alarm.

Description

No movement detected was detected at all when a motor was commanded to move. The alarm indicates both which motor that has failed (boom, tower, wheels, telescope, arm or nozzle) and in which direction.

Troubleshooting

- Check that pulses are received from given motor in the detailed view on the [Manual screen](#)
- Check that motor is turning physically

From:
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tss_missing_pulses?rev=1599815915

Last update: **2020/09/11 02:18**

