

Motor stuck in a given direction

This is a [soft](#) alarm. However, the alarm will be accompanied by a [robot stuck](#) alarm.

Description

No movement detected for a couple of seconds while the target position has not been reached yet, i.e. the motor has started moving but then stopped before reaching the desired position. The alarm indicates both which motor that has failed and in which direction.

Troubleshooting

- Check that the motor is working
- Check that the robot has not run into anything
- Check hose and hose spreader
 - [Hose grows on the reel](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tss_motor_stuck?rev=1591012242

Last update: **2020/06/01 04:50**

