

No current detected for given function

This is a [soft](#) alarm.

Description

No movement detected was detected at all when a motor was commanded to move. At the same time, no significant current was measured.

Troubleshooting

- Check motor cabling

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tso_no_current

Last update: **2020/07/14 10:21**

