

Ongoing wash aborted unexpectedly

This is a [hard](#) alarm.

Description

An ongoing automatic wash was aborted unexpectedly.

Troubleshooting

Most probably caused by power loss. Check that the batteries are charged and that cables/connectors are not damaged. It can also be set off by powering off the robot during washing.

See also [Robot restarts unexpectedly](#)

From:
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tso_ongoing_wash_aborted_unexpectedly

Last update: **2025/06/07 23:01**

