

Ongoing wash aborted unexpectedly

This is a [hard](#) alarm.

Description

An ongoing automatic wash was aborted unexpectedly.

Troubleshooting

Most probably caused by power loss. Check that the batteries are charged. It can also be set off by powering off the robot during washing.

From:
<https://wiki.envirologic.se/> - Envirologic Support Wiki

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tsa_ongoing_wash_aborted_unexpectedly?rev=1578413167

Last update: **2020/01/07 08:06**

