

# Ongoing wash aborted unexpectedly

This is a [hard](#) alarm.

## Description

An ongoing automatic wash was aborted unexpectedly.

## Troubleshooting

Most probably caused by power loss. Check that the batteries are charged. It can also be set off by powering off the robot during washing.

From:  
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:  
[https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tsa\\_ongoing\\_wash\\_aborted\\_unexpectedly?rev=1595337264](https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tsa_ongoing_wash_aborted_unexpectedly?rev=1595337264)

Last update: **2020/07/21 06:14**

