

Reel missing pulses

This is a [soft](#) alarm.

Description

No movement detected was detected at all when a motor was commanded to move.

Troubleshooting

- Check that pulses are received from reel motor
- Check that motor is turning

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:tss_reel_missing_pulses?rev=1580633029

Last update: **2020/02/02 00:43**

