

Wheels stuck

This is a [soft](#) alarm. However, the alarm will be accompanied by a [robot stuck](#) alarm.

Description

The wheels [motor has stuck](#) in the given direction (forwards or backwards), i.e. no significant movement has been detected for a couple of seconds when the motor was expected to move. The motor is stuck due to a physical obstacle or other environmental changes.

Troubleshooting

- Check that the robot wheels have not run into an obstacle too high to overcome
- Check that the robot guidance wheels have not run into an protruding feature to large to overcome
- If the robot has got stock on the side opposite to the guidance wheels, it could be an indication of poor programming
- Check that the wheels motor is working
- Check that the marker sensor is working

See more information under [guidance wheels recommendations](#)

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

https://wiki.envirologic.se/doku.php/troubleshooting:alarm:wheels_stuck?rev=1701892177

Last update: **2023/12/06 11:49**

