

# Hose does not reel in

A number of different causes are possible

- Hose stuck
  - Check that the reel is moving freely by manually turning it
- [Hose grows on reel](#)
- Chain has jumped off
- Motor is broken
  - Check if PLB software is 1.17 or above (softer motor drive)
- Motor cable is damaged

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

[https://wiki.envirologic.se/doku.php/troubleshooting:no\\_alarm:hose\\_does\\_not\\_reel\\_in?rev=1595315941](https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:hose_does_not_reel_in?rev=1595315941)

Last update: **2020/07/21 00:19**

