Hose does not reel in

A number of different causes are possible

- Hose stuck
  - Check that the reel is moving freely by manually turning it
- Hose grows on reel
- Chain has jumped off
- Motor is broken
  - Check if PLB software is 1.17 or above (softer motor drive)
- Motor cable is damaged

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:hose_does_not_reel_in?rev=1595315941

Last update: **2020/07/21 00:19**