

Problem with motor

Description

Motor issues can arise from a number of reasons:

- Damaged cables leading to circuit breaks or short circuits
- Damaged connectors or water ingress in connectors
- Damaged gears

Troubleshooting

Always troubleshoot the motor from the [Manual screen](#). Run it at least 5 seconds in each direction. Press the “i” button for a detailed view.

- Does the position counter change? If not, check the pulse signal and power cables.
- Does the function move physically? If not:
 - Does any sound come from the motor? If it does, the function could be physically stuck or the gear can be damaged

From:
<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/troubleshooting:no_alarm:motor_problem?rev=1600087397

Last update: **2020/09/14 05:43**

