Electrical drawings

Here you can find the electrical drawings and pin data for the EVO Cleaner, making it easier to troubleshoot

---

Boom

Chassi, Chassi rev210301

Connection instructions, Connection instructions rev210222, Connection instructions rev210301

Main, Main rev210222, Main rev210301

Joystick connections

From:
https://wiki.envirologic.se/ - **Envirologic Support Wiki**

Permanent link:
https://wiki.envirologic.se/doku.php/user_manuals:electrical_drawings

Last update: **2024/02/05 01:36**