

Connectors

Batteries

The batteries are connected with quick release type connectors. To avoid short circuits when replacing the batteries, always first remove the connector from the minus pole of the battery connected to the robot. Consequently, always reconnect this pole last.

Motors

The motors are connected with sealed connectors. The most exposed ones (arm and nozzle) are striped with cable ties for extra water protection.

Joystick

The [joystick connector](#) is located under the hood on the right side of the robot.

Charger

The [charging connector](#) is located on the back side of the robot below the panel.

Hose

The standard hose is fitted with a 3/8" male BSP thread connector.

From:

<https://wiki.envirologic.se/> - **Envirologic Support Wiki**

Permanent link:

<https://wiki.envirologic.se/doku.php/parts:connectors>

Last update: **2020/09/21 06:55**

